## **CANPLAS®** PLUMBING SOLUTIONS



By puncturing the PVC membrane with a utility knife, wastewater is drained slowly, avoiding the typical torrent of wastewater mess with other test methods.

Simply remove the membrane with a knife after the system is tested.







## **PermOseal**®

## 4"x3" Reducing Line Cleanout with Test Membrane

**New!** Innovative test membrane from Canplas® enables mess-free removal of the test membrane after a water test.



PART#	MATERIAL	DESC.	CTN. QTY.
112107AT	ABS	4" x 3" x 4"	15
212107WAT	PVC	4" x 3" x 4"	15

Canplas Industries Ltd. 500 Veterans Drive, P.O. Box 1800 Barrie, Ontario, Canada L4M 4V3 Tel: (705) 726-3361 **Toll Free: 1-800-461-5300** 

Fax: (705) 726-2186



